

Analog Electronics

Semiconductor diodes

B. Sc. SY




Asst. Prof. S. K. Jogdand
Physics & Electronics Department
Shri Shivaji College of Arts, Commerce and Science, Kandhar

Contents:

- Introduction
- Diode identification
- Diode Operation
- Testing a Diode
- Diode Application

Semiconductors

- A material whose properties are such that it is not quite a conductor, not quite an insulator
- Some common semiconductors
 - elemental
 - Si - Silicon (most common)
 - Ge – Germanium
 - Both are group 4 elements.
 - compound
 - GaAs - Gallium arsenide
 - GaP - Gallium phosphide
 - AlAs - Aluminum arsenide
 - AlP - Aluminum phosphide
 - InP - Indium Phosphide



Improving Conduction by Doping

- To make semiconductors better conductors, add impurities (dopants) to contribute extra electrons or extra holes
 - elements with 5 outer electrons contribute an extra electron to the lattice (**donor** dopant)-**produces n type silicon**
 - elements with 3 outer electrons accept an electron from the silicon (**acceptor** dopant)-**produces p type silicon**

Introduction to diodes

- The simplest form of a diode is the p-n (positive-negative) junction diode .
- The diode is contained in a small capsule made of glass or plastic and has two terminals or electrodes and hence the name diode (di \equiv two and ode \equiv electrode).
- The electrode connected to the p-type is called the Anode “A”, and the electrode connected to the n-type is called the Cathode “K”.

Diode Types

According to semiconductor material used:

- Germanium diodes
- Silicon diodes

Application

- Rectifier diodes.
- Zener diodes.
- Light emitting diodes (LEDs).
- Photo diodes.
- Small Signal (low power) diodes.

Typical diodes of different types



LED



Rectifier diode



Low Power Diode



Zener Diode



Photo Diode

Diode identification: Pro-Electron System & JEDEC System

1.1 Pro-Electron Numbering or Coding System

First Letter Specifies Semiconductor Material		Second Letter Specifies type of Diode	
A	Germanium	A	Low power or signal
B	Silicon	P	Light detector
EXAMPLE: BZY74-C6V3 B = Si, Z = Zener diode, Y74 = Commercial or Industrial use, C = 5% of rating voltage. 6V3 = 6.3 Volt (Voltage rating)		Q	Light Emitting Diode (LED)
		Y	Rectifier
		Z	Zener (voltage reference)

1.2 JEDEC Numbering or Coding System

First Number	Second Letter	Subsequent numbers
1	Diode	N Semiconductor
2	Bipolar Transistor	Example: This code "1N4001" means:
3	FET	1 ≡ Diode, N ≡ Semiconductor.
4&5	Photo Coupler	4001 ≡ Serial number.

Pro-Electron System originated in **Europe** and is widely used for semiconductor devices developed and manufactured by European manufacturers

JEDEC System: This numbering system originated in the **USA** and is widely used for semiconductors manufactured in North America

Diode Operation


- A diode conducts only in **one** direction.
the conduction is from **anode** to **cathode**.
- **Biassing:** Arranging a diode suitably in a circuit is called biasing

There are two types of diode biasing:

- **Forward bias**
- **Reverse bias**

Figure 1.4: Diode operated in forward bias

- When a diode is connected to the power supply such its **anode (A)** is connected to the **positive terminal**, and its **cathode (K)** is connected to the **negative terminal** as shown in figure ,we say that it is **forward biased (FB)**.
- The diode in FB-direction allows the current to flow from A to K as shown in Figure 1.4



Diode operated in reverse bias

Reverse biased:

A diode is **reverse biased (RB)** when its **anode (A)** is **negative** with respect to the **cathode (K)**.

The diode in RB-direction does not allow the current to flow as shown in Figure 1.5.





Figure 1.6: Diode characteristics curve




Diode characteristics curve

- Diode's **forward voltage** and **reverse voltage** are measured along the **positive** and **negative** x-axes respectively, while diode's **forward current** and **reverse current** are measured along the **positive** and **negative** y-axes respectively.
- Note that the diode needs a **minimum voltage** (called **threshold** or barrier or knee voltage) **before** it starts **conducting** (passing current) in the forward bias.
- The threshold voltage is around **0.3V** and **0.7V** for **Germanium** and **Silicon** diodes respectively.


Testing the diode in FB direction using multimeter

- Set the digital Multimeter knob to 'diode testing' function.
- Now, connect the positive lead (Red) to the **anode (A)** and the negative lead (Black) to the cathode (K) as shown in Figure 1.8a.
- For a **diode in a good condition** the reading will be in the range of $\leq 0.3V$ for Ge and $\leq 0.7V$ for Si.




Testing the diode in FB direction using ohmmeter

- Connect the positive meter-lead (Red) to the **anode (A)** and connect the negative meter-lead (Black) to the cathode (K) as shown in Figure 1.7a.
- A good diode must display **low resistance (typically $< 10\Omega$)** in FB.
- Note that the ohmmeter consists of an internal battery (1.5 V), which can FB or RB a diode.



Testing the diode in RB direction using ohmmeter

- Connect the positive meter-lead (Red) to the cathode (K), and the negative meter-lead (Black) to the anode (A) as shown in Figure 1.7b.
- A good diode must display a **very high resistance ($>1000\text{ M}\Omega$)** in RB.



Diode Application

- Diode has a unique ability to offer very **little resistance** to current flow in the **forward-bias direction**, but **maximum resistance** to current flow when **reverse biased**. For this reason, diodes are used in rectification.
- *Rectification is the process of converting AC signal to pulsating DC signal, and the diodes used for this purpose are called rectifier diodes.*

AC current behavior for a sine-wave:

- During the **positive half-cycle**, AC current flows first in one direction, reaches the **maximum (positive)** and **decreases to zero**.
- During the **negative half-cycle**, the current follows in the same manner in the **opposite direction**.
- In each cycle, AC current reverses its direction as shown in Figure 1.9.